

# HIKOKI

## SABER SAW CR13V

Item No.	Code No.	Description	No. Used	Remarks
1	321116	BASE (B)	1	
2	321125	FRONT COVER (C)	1	
3	321132	BLADE HOLDER (A)	1	
4	949554	NUT M4 (10 PCS.)	1	
5A	333738	PLUNGER (B) ASS'Y	1	INCLUD.3,4,15-20
6	321123	GEAR COVER (B)	1	
7	318458	FELT WASHER	1	
8	321117	WASHER (H)	1	
9	318459	V-RING	1	
10	321118	O-RING	1	
11	321214	METAL (B)	1	
12	321136	SWING ROLLER	2	
13A	326585	PIN D6	1	
14	321126	COVER CLIP	1	
15	322134	SPECIAL BOLT M4	1	
16	321130	CAP	1	
17	321131	LEVER (A)	1	
18	321135	SPRING (D)	1	
19	321134	HOLDER PIN (B)	1	
20	318483	SPRING (B)	1	
21	318451	NYLOCK BOLT (W/FLANGE) M6X35	1	
22	318452	WASHER (G)	1	
23	322142	NYLOCK BOLT (W/FLANGE) M5X12	1	
24	6002DD	BALL BEARING 6002DDCMPS2L	1	
25	317196	NYLOCK BOLT (W/FLANGE) M4X12	3	
26	322119	SUB SHAFT (B)	1	
27	967261	RETAINING RING FOR D17 SHAFT	1	
28	322118	RECIPRO PLATE	1	
29	6003VV	BALL BEARING 6003VVCMP2L	2	
30	939556	RETAINING RING FOR D35 HOLE (10 PCS.)	1	
31	321128	SECOND SHAFT (B)	1	
32	318473	GEAR	1	
33	608VVM	BALL BEARING 608VVC2PS2L	1	
34	321124	INNER COVER (B)	1	
35	6001VV	BALL BEARING 6001VV	1	
36	314430	SLOTTED HD. SCREW (SEAL LOCK) M4X10	2	
*37	360616E	ARMATURE 220V-230V	1	
38	321122	FAN GUIDE	1	
39	953174	HEX. HD. TAPPING SCREW D5X55	2	
*40	340563J	STATOR ASS'Y 220V-230V	1	INCLUD.41
41	930703	BRUSH TERMINAL	2	
42	608VVM	BALL BEARING 608VVC2PS2L	1	
43	322120	HOUSING	1	
44	945161	BRUSH CAP	2	
45	999043	CARBON BRUSH (1 PAIR)	2	
46	958900	BRUSH HOLDER	2	
47		NAME PLATE	1	
48	307224	MACHINE SCREW (W/WASHERS) M5X60 (BLACK)	4	
49		BRAND LABEL	1	
50	307028	TAPPING SCREW (W/FLANGE) D4X25 (BLACK)	5	
51A	324823	HANDLE (C).(D) SET	1	
52	981373	TUBE (D)	4	
53	322133	SWITCH TRIGGER	1	

\* ALTERNATIVE PARTS



