

HIKOKI

CORDLESS CHAIN SAW CS3630DB

Item No.	Code No.	Description	No. Used	Remarks
1	377208	TAPPING SCREW (W/WASHERS) D4X18	4	
2	377204	FRONT HANDLE	1	
3	377185	TANK CAP SET	1	
4	338803	RUBBER RING	1	
5	377205	TAPPING SCREW D4X16	26	
6	377190	BRAKE HANDLE SET	1	
7	377199	BRAKE STOPPER	1	
8	377198	STOPPER SPRING	1	
9	377184	OIL TANK SET	1	
10	373913	MV LABEL (A)	1	
11A	381418	HOUSING SET	1	
12	377186	PUMP CONNECTOR SET	1	
13	377193	TAPPING SCREW (W/FLANGE) D3X12	2	
14	338821	EXTENSION SPRING	1	
15	377187	MOTOR SET	1	
16	338798	SPRING	1	
17	338799	SPROCKET	1	
18	974577	RETAINING RING (E-TYPE) FOR D7 SHAFT	1	
19	335967	ADJUSTING BOLT	1	
20	377194	FAN COVER	1	
21	338797	SPIKE	1	
22	377201	SEAL RING	1	
23	377202	INSULATION BRACKET	1	
24	377206	GUIDE BAR 12"	1	
25	377211	SAW CHAIN (3/8X12")	1	
26	377192	CHAIN SIDE COVER SET	1	
27		BRAND LABEL	1	
28	377200	TAPPING SCREW (W/SP. WASHER) D5X25	3	
29	373914	MV LABEL (B)	1	
30	377203	FLAT HD. SCREW M4X12	2	
31	377191	CHAIN PULLER SET	1	
32		NAME PLATE	1	
33	377189	TRIGGER ASS'Y	1	INCLUD.34,35
34	377197	TRIGGER SPRING	1	
35	377196	LOCK OFF SPRING	1	
36A	381419	BATTERY TERMINAL HOLDER SET	1	
37A	381420	CONTROLLER	1	
		STANDARD ACCESSORIES		
501	377207	CHAIN COVER 12"	1	
502		OIL FEEDER (50CC)	1	
				SUPPLIED WITH ITEM NO.601
		OPTIONAL ACCESSORIES		
601	957681	LUBRICANT OILER (120CC)	1	

* ALTERNATIVE PARTS

