

# HIKOKI

## CORDLESS PLANER P18DSL

Item No.	Code No.	Description	No. Used	Remarks
*1	334480	CUTTER BLOCK ASS'Y (W/B.B)	1	INCLUD.17,19 EXCEPT FOR IND
*2	336571	PLANER BLADES (1 PAIR)	2	FOR DOUBLE EDGE BLADE TYPE
*3	334478	SET PLATE (B) (1 PAIR)	2	FOR DOUBLE EDGE BLADE TYPE
*4	314754	SET PLATE (A)	2	EXCEPT FOR IND
*5	949423	WASHER M4 (10 PCS.)	4	EXCEPT FOR IND
*6	949213	MACHINE SCREW M4X5 (10 PCS.)	4	EXCEPT FOR IND
*7	316398	BLADE HOLDER (1 PAIR)	2	EXCEPT FOR IND
8	336574	BOLT M6	6	
17	608VVM	BALL BEARING 608VVC2PS2L	2	
19	6200VV	BALL BEARING 6200VVCMP2L	2	
20	958945	SCREW PLATE	1	
21	954004	TAPPING SCREW D4X16	1	
22	958709	SPRING	1	
23	958708	RUBBER PACKING	1	
24A	336986	FRONT BASE	1	
25	301631	SPRING (F)	1	
26	336481	KNOB	1	
27	334494	KNOB (A)	1	
28	334497	LOCK NUT M10	1	
*29	336486	KNOB (B)	1	
30	301659	WASHER (B)	1	
31		NAME PLATE	1	
32	334501	TIP COVER	1	
33	333163	MACHINE SCREW (BLACK) M4X16	3	
34	336490	BRUSH CAP	2	
35	999017	CARBON BRUSH (1 PAIR)	2	
36	334492	BEARING COVER	1	
37	309470	TAPPING SCREW (W/FLANGE) D4X12 (BLACK)	2	
38	301653	TAPPING SCREW (W/FLANGE) D4X20 (BLACK)	11	
39	336485	TAIL COVER	1	
40	336576	BRUSH HOLDER	1	
*42B	336575	BELT COVER	1	
43	958718	BELT	1	
44	336489	PULLEY (B)	1	
45	334486	END BRACKET	1	
46	360969	ARMATURE DC 18V	1	
47	334493	FAN GUIDE	1	
48	319846	MAGNET	1	
49	336488	PULLEY (A)	1	
50	336484	HANDLE COVER	1	
51	319825	SWITCH (1P SCREW TYPE) W/O LOCK	1	
52	960108	HEX. HD. TAPPING SCREW D4X60	2	
53	319290	WASHER	2	
54	336482	HOUSING	1	
*55A	375955	CONTROLLER TERMINAL SET (W/FERRITE CORE)	1	FOR EUROPE,ISR,KOR,TUR,SAF
56	334838	REAR BASE	1	
57	307811	TAPPING SCREW (W/FLANGE) D4X16 (BLACK)	4	
58	334499	STAND	1	
59	334500	SPRING	1	
*60	330068	BATTERY BSL 1830 (EUROPE,AUS,NZL)	2	INCLUD.508
*60	336385	BATTERY BSL 1850(EUROPE,AUS,NZL)(2 PCS.)	2	INCLUD.508
		STANDARD ACCESSORIES		
502	940543	BOX WRENCH 10MM	1	

\* ALTERNATIVE PARTS



