


Partdrawing for HR2811F - Combihamer



Nr.	Part nr.	Name
001*	286263-4	Rubber Stofkap 35 Hr2440/50
002	233940-9	Borgring 19 Hr2440/50 A
003	417629-9	Boorhouderkap Hr2440/50
004	257241-1	Ring 21 Hr2440/50
005	345187-4	Geleidering Hr2440/50
006	233916-6	Drukveer 21-29 Hr2440/50
007	922241-7	Inbusbout M5X25Mm
008	158057-6	Handgreep Hr2230 Rubber A
009	265495-6	Zeskantbout M8X110 A
010	419975-6	Handgreepbeugel Hr2811
011	158288-7	Cilinderhuis Cpl Hr2811
012	267354-0	Revet 31 Hr2811C
013	262133-1	Urethaan Ring 31 Hr2811
014	267354-0	Revet 31 Hr2811C
015	234020-4	Drukveer 37 Hr2811
016	419986-1	Blokkeerbus Hr2811
017	233952-2	Veerring 41 Hr2811
018	213620-3	O-Ring 46
019	922128-3	Inbusbout M4X16
020	419984-5	Krukashuisbedekking Hr2811
021*	216022-2	Stalen Kogel 7.0 Hr2400
022	123191-1	Boorhouder Compl.Hr2811F A
023	213344-1	Keerring 9 Hr2811 A
024	961140-8	Borgring Hr2811
025	331769-8	Bus Hr2230
026	324669-9	Slagstuk Bhr240
027	324402-9	Ring 10 Hr2450Ft
028*	421955-0	Stootring Bhr240
029	324216-6	O-Ring Huis Hr2440/50
030*	213073-6	O-Ring 9 Hr2440/50
031*	233917-4	Veerring 28 Hr2440/50
032	267105-1	Sluitring 29 Hr2400
033	234021-2	Drukveer 20 Hr2811
034	331770-3	Geleidebus Hr2811
035	213435-8	O-Ring 26 Hr3000C
036	256099-5	Pen 6
037	324733-6	Slaghamer Hr2460
038*	213227-5	O-Ring 16 Hk0500
039	331776-1	Zuiger Hr2811
040	233954-8	Veerring 21 Hr2811
041	158282-9	Drijfstang Hr2811
042	227532-4	Tandwiel 31 Hr2811
043	266420-0	Schroef 4X20 Hr2811
044	234019-9	Drukveer 4 Hr2811
045	345814-3	Verbindingsplaat Hr4510C
046	345815-1	Geleidingsplaat Hr2811

Nr.	Part nr.	Name
047	911116-5	Schroef 4X12 A
048	213262-3	O-Ring 18
049	162256-4	Verbindingsring Hr2811
050	419988-7	Filterkap Hk1820
051	213218-6	O-Ring 16 HK1820 P
052	443129-3	Filter Hk1820
053	419987-9	Krukashuis Kap Hr2811
054	213406-5	O-Ring 30
055	158289-5	Krukashuis Cpl Hr2811
056	324793-8	Krukas Hr2811
057	211232-6	Kogellager 6002Llu
058	961055-9	Borgring S-15
059	233951-4	Drukveer 16-26 Hr2811
060	223167-9	Koppeling Hr2811
061	226653-9	Tandwiel 29 Hr2811
062	267353-2	Revet 29 Hr2811C
063	961034-7	Borgring Hr2811
064	345818-5	Schotelring 16 Hr2811
065	254239-9	Inlegspie 4 Hr4013C
066	227524-3	Tandwiel 9 Hr2811
067	254239-9	Inlegspie 4 Hr4013C
068	211138-8	Kogellager 6001Llu
069	125386-2	Koppelbegrenzer Hr2811
070	961006-2	Borgring S-10 EBH341L P
071	210024-0	Kogellager 608 2Rs Hr5001C
072	424028-8	Pakkingring Hr2811
073	158287-9	Tandwielhuis Cpl Hr2811
074	213407-3	O-Ring 26 A
075	213133-4	Keerring 12 Hr3210Fct P
076	331775-3	Bus 10 Hr2811
077	210054-1	Kogellager 6000Llu
078	253171-4	Sluitring 10 Bst220/Hr2811
079	240095-3	Waaier 64 Hr2811
080	515294-9	Anker Hr2811
081	266325-4	Tap Schroef 4X70Mm P
082	210045-2	Kogellager 627Ddw A
083	681656-4	Isolatieing Gd0800C
084	419989-5	Opvulplaat Hr2811
085	526584-5	Veld Hr2811
086	419982-9	Motorhuisset Hr2811
087	643766-5	Koolborstelhouder Hr2811
088	266421-8	Schroef 3X10 Hr2811 A
089	194074-2	Koolborstel Set Cb-325
090	631754-4	Licht-Circuit Hr2811
091	419983-7	Onderdeksel Hr2811
092	266326-2	Tap Schroef 4X18mm P

Nr.	Part nr.	Name
093	638568-2	Condensator Hr2811
094	638567-4	Draadboom Hr2811
095	638566-6	Draadboom Hr2811
096	266326-2	Tap Schroef 4X18mm P
097	158284-5	Verstelknop Hr2811
098	234022-0	Drukveer 14 Hk1820
099	266326-2	Tap Schroef 4X18mm P
100	419995-0	Veergeleider Hr2811
101	419979-8	Achterhuis Hr2811
102	911258-5	Schroef 5X35 A
103	266420-0	Schroef 4X20 Hr2811
104	863925-7	Naamplaat Hr2811F
105	419992-6	L/R Verstelhendel Hr2811
106	419994-2	Stofkap Hr2811
107	424029-6	Stofafdichting Hr2811
108	419978-0	Handgreep Hr2811
109	631753-6	Stroomcircuit Hr2811
110	419990-0	Schakelknop Hr2811
111	158281-1	Schakelknophouder Hr2811
112	650591-7	Schakelaar Hr2811
113	419980-3	Handgreepdeksel Hr2811
114	266326-2	Tap Schroef 4X18mm P
115	695123-3	Netsnoer 2X1.50 4.0Mtr A
116	682573-1	Kabeltule 10 Ga9010C A
117	266326-2	Tap Schroef 4X18mm P
118	687169-3	Trekontlaster Hp1621
119	685722-9	Spons Ring 4302C
120	313139-3	Kraagbus 6 HK1820 P
121	266041-8	Tapschroef 5X25 A