HiKOKI

USB POWER ADAPTER

Item No.	Code No.	Description	No. Used	Remarks
*1	383215	POWER CHARGER	1	
*1	383214	POWER CHARGER	1	FOR AUS,NZL
*1	383216M	POWER CHARGER	1	FOR USA,CAN
		STANDARD ACCESSORIES		
501	383207	USB CABLE	1	
*502	383211	AC-ADAPTER	1	
*502	383212	AC-ADAPTER	1	FOR GBR
*502	383210	AC-ADAPTER	1	FOR AUS,NZL
*502	383209	AC-ADAPTER	1	FOR USA,CAN

* ALTERNATIVE PARTS