HiKOKI

CHARGER

Item No.	Code No.	Description	No. Used	Remarks
1	329634	CASE (A)	1	
*2	329856	CORD	1	FOR GBR
*2	331985	CORD	1	FOR BRAZIL
2A	337634	CORD	1	FOR USA,CAN
2A	337635	CORD	1	FOR EUROPE
2A	337906	CORD	1	FOR AUS
3		PRINTED CIRCUIT BOARD ASS'Y 120V	1	
				INCLUD.4
3		PRINTED CIRCUIT BOARD ASS'Y 230V-240V	1	
				INCLUD.4
4	326285	TERMINAL (A)	7	
5	329635	CASE (B)	1	
6	326358	TAPPING SCREW (W/FLANGE) D3X18	3	
7		NAME PLATE	1	

* ALTERNATIVE PARTS



Rev.3

形　名
UC18YGL2